

Permitir Jumbo Frames en Cisco

Para permitir Jumbo Frames en cisco deberemos teclear los siguientes comandos

```
policy-map type network-qos jumbo  
class type network-qos class-default mtu 9216  
system qos service-policy type network-qos jumbo
```

Revision #1

Created 19 May 2022 06:22:34 by Admin

Updated 19 May 2022 06:22:46 by Admin